

## Hoist Link Sticks

Used with strap hoists for extra insulation when tensioning conductors. Safety hook one end, swivel eye the other end. 3 sizes available.



CAT NO	DESCRIPTION
3413	6" (152mm) Fibreglass Hoist Link Stick
3414	12" (305mm) Fibreglass Hoist Link Stick
EX3-057	24" (610mm) Fibreglass Hoist Link Stick

## Spiral Link Sticks

Used to isolate ropes or conductors when used in conjunction with hoisting equipment. Spiral hook one end, swivel eye the other end. 3 sizes available.



CAT NO	DESCRIPTION
3480	12" (305mm) Fibreglass Spiral Link Stick
3481	24" (610mm) Fibreglass Spiral Link Stick
3482	36" (915mm) Fibreglass Spiral Link Stick

## Conductor Tensioning Tool

Used for temporarily isolating sections of line for changing tension insulators or conductor splices for hot stick or rubber gloving work. Maximum take up 12" (305mm).



CAT NO	LENGTH CLOSED	LENGTH EXTENDED
3465	71" (1803mm)	83" (2108mm)

## Pole Mounted Side Arm

Supports one or two conductors when changing pole cross arms or insulators. Ratchet strap binder allows quick and easy installation onto pole. Comes with 2 'U' type conductor holders, but can be used with 'C' type wire holders where live working procedures indicate conductor is covered with linehose.



CAT NO	LENGTH	DESCRIPTION
5038	34" (864mm)	Pole Mounted Side Arm with 1 x 'U' type conductor holder
5040	48" (1219mm)	Pole Mounted Side Arm with 2 x 'U' type conductor holder
A10038	-	'C' Type wire holder - large opening for Linehose

## Parking Bars

Designed for safely parking energised jumpers during live working operations. Two types available.

CAT NO	DESCRIPTION
12577	Spring loaded clamp with 15" (381mm) of fibreglass shaft. Steel hanger bar
3478	Screw type clamp with 24" (610mm) of fibreglass shaft. Fibreglass hanger bar

